

Use these guidelines to keep your electric lift clean and your operators protected from coronavirus, germs, and other contaminants.



WHAT TO USE:

- Soap and water
- Alcohol wipes
- Alcohol and water
- Disinfectant wipes

WHAT NOT TO USE:

- Straight bleach on any plastic element
- Chlorine-based cleaners on aluminum

MAKE SURE TO CLEAN:

- Entire surface of both handles
- All buttons and main control panel
- Front caster rings
- Platform handle
- Platform surface, including top and all edges

RECOMMENDED:

- Wear disposable gloves
- Disinfect or wash hands before and after using the lift.

The guidelines provided are intended as suggestions and for informational purposes only. This is not intended to replace or substitute for any policies, procedures, or directives provided by the company/facility in which the lift is used, local, state, or federal agencies, or any other jurisdictional authority.

 **STAY CLEAN & STAY SAFE!**

 **serverLIFT**