**The ServerLIFT WS-1X Wide Shelf add on attachment provides additional reach to our standard ServerLIFT SL-350X, SL-500X, or SL-1000X Platform.**

## INCLUDED WITH WS-1X WIDE SHELF:

- (1) Wide Shelf Plate
- (4) Flat Head Screws
- (1) Hex Wrench

## INSTALLING THE WS-1X WIDE SHELF ON SL-500X OR SL-350X LIFTS:

1. Place Wide Shelf Plate onto ServerLIFT SL-500X or SL-350X data center lift. Line up securing screw holes of plate with threaded holes on SL-500X or SL-350X Equipment Platform. *NOTE: Serial number and labels of Wide Shelf Plate should be facing down.*

2. Secure Wide Shelf Plate to the SL-500X or SL-350X Equipment Platform with provided Flat Head Screws using provided Hex Wrench in all four locations as shown.

# INSTALLING THE WS-1X ON SL-1000X:

1. Unscrew and remove D-rings from Wide Shelf Plate and store in a secure place.

2. Place Wide Shelf Plate onto ServerLIFT SL-1000X Equipment Platform. Line up securing screw holes of Wide Shelf Plate with threaded holes on SL-1000X Equipment Platform. *NOTE: Serial number and labels of Wide Shelf Plate should be facing down.*

3. Secure Wide Shelf Plate to the SL-1000X Equipment Platform with provided Flat Head Screws using provided Hex Wrench in all four locations as shown.

**ServerLIFT Corporation**
17453 N. 25th Ave. Phoenix, AZ 85023
P: 602.254.1557   F: 602.254.1975
www.serverlift.com

serverLIFT®

*Please read and completely understand the contents of the ServerLIFT Operator's Manual before operating the Server-LIFT device. Failure to read, understand, and follow instructions in the manual may result in property damage and/or personal injury. If you do not understand any part of this manual or if you have any questions please contact ServerLIFT Service & Support.*

**Service & Support:**
support@serverlift.com

**Shipping/Recieving:**
shipping@serverlift.com

**Sales:**
sales@serverlift.com

**11-2019  r.A03**